#### $\equiv$

## Relationships

Relationship	Product
Colorway Product	B252 Boys RL White/Dyed & Dunk Stripe Exp WB OE Brief (Colorways BIW)
Pattern Product	T0409 BoysSize:XS-2X Rib - Body 1x1 Brief (Innerwear Boys Patterns)
Label Product	LP 10056 Boys' Underwear Hanes Comfort Flex Tagless Btm (Mkt-Boys' UW Garment Labels)
Selling Product	SP- 21813 - B252P6 - P 6 - White Alpha Brief (BIW Active Year)

Report	Name J#
Construction	001 : KB001A-Exposed WB brief w/ front panel, bound fly/legs
Measurements	001 : T0409A FGM

# Colorways

# Colorways by Group

Colorway Group	L Colorway Name	1 常
Basic Heathers	( LCU ) CW 15042 B252 Grey Heather	
Basic Heathers	( LFU ) CW 15045 B252 Mid Blue Heather	
Basic S14 Dunk Stripes	(11U) CW 15050 B252 B-DS-SP14-2	
Basic S14 Dunk Stripes	( 10U ) CW 15051 B252 B-DS-SP14-1	
Basic S14 Dunk Stripes	( 13U ) CW 15053 B252 B-DS-SP14-4	
Basic S14 Dunk Stripes	( 12U ) CW 15052 B252 B-DS-SP14-3	
Basic S14 Dunk Stripes	( WYU ) CW 15054 B252 B-DS-SP14-10	
Basic S15 Dunk Stripes	( 3LU ) CW 17072 E-DS-SP15-03 B252	
Basic S15 Dunk Stripes	( 3JU ) CW 17074 E-DS-SP15-01 B252	
Basic S15 Dunk Stripes	( 3KU ) CW 17075 E-DS-SP15-02 B252	
Basic S15 Dunk Stripes	( 3MU ) CW 17073 E-DS-SP15-04 B252	
Basic Solids	( EUU ) CW 16181 Royalty Blue B252	
Basic Solids	( ) CW 17076 Kiwi Ice B252	
Basic Solids	() CW 17853 Best Red B252	
Basic Solids	( ) CW 16191 White B252 w/Grey Elastic	
Basic Solids	( ) CW 17793 Optical Blue B252	
Basic Solids	( 06U ) CW 15044 B252 Black	
Basic Solids	( WHU ) CW 15015 B252 White	

# Measurements

POM J	Measurement Name	Placement Amount	Placement Reference	Plus Tolerance	Minus Tolerance	HTM Instructions	Comments	xs ↓ţ	s 🎼	M ↓	L ↓	XL ↓♣	2X ↓
200a	Waist - at top (half)			0.75	0.75		kids (c1) tolerance	9.25	10.25	11.0	12.0	13.0	13.5
200x	Min. Waist - Extended (half)			99.0	0.0			13.5	14.75	16.0	17.5	19.0	19.75
300	Waistband Width / Height			0.25	0.25		(c1) tolerance	1.25	1.25	1.25	1.25	1.25	1.25
210	Rise/Trunk Length - Flat			0.75	0.75		kids (c1) tolerance	9.0	9.5	10.5	11.375	12.125	12.75
210a	Front Rise - Top of Waistband			0.75	0.75		kids (c1) tolerance	10.625	11.125	12.125	13.0	13.75	14.375
211a	Back Rise - Top of Waistband			0.75	0.75		kids (c1) tolerance	7.375	7.875	8.875	9.75	10.5	11.125
215	Fly Length			0.25	0.25			2.75	3.0	3.25	4.0	4.75	5.25
215b	Fly Position			0.25	0.25			1.75	1.875	2.0	2.125	2.125	2.125
243	Panel Width - 4" Down (front or back)	4		0.5	0.5		(c1) tolerance	3.5	3.625	3.75	4.0	4.25	4.375
245b	Crotch Width - At Seam (front or back)			0.25	0.25			3.875	4.0	4.125	4.375	4.625	4.75
202e	Seat - At Top of Leg (half)			0.75	0.75		kids (c1) tolerance	8.625	9.625	10.625	11.75	12.875	13.375
206a	Leg Opening - At Edge (half)		Inseam 0-2	0.5	0.5		short-kids (c1) tolerance	6.125	6.75	7.375	8.375	9.25	9.875
206x	Min. Leg Opening - Extended (half)		Inseam 0-2	99.0	0.0			7.875	8.75	9.5	10.25	11.0	11.375
209a	Outseam - Top of Waistband		Inseam 0-2	0.5	0.5		short-kids (c1) tolerance	4.375	4.625	5.125	5.375	5.5	5.625
302	Leg Trim / Binding Width / Height			0.125	0.125			0.5625	0.5625	0.5625	0.5625	0.5625	0.5625
302	Fly Trim / Binding Width / Height			0.125	0.125			0.3125	0.3125	0.3125	0.3125	0.3125	0.3125

# Constructions


Sewing Operation	Stitch Type / / Description	Gauge Width	SPI≑	Seam/Trimoff	Garment Use	Needle Thread	Needle Visibility	Looper Thread	Looper Visbility	Comments
Seam waist elastic with latch-tack.	503 2 thread overedge	12gg / 4.8mm	25 min	1/8" trimoff	Waist	T18 Txt Poly	Side B	T18 Txt Poly	Side A/B	
Bind fly.	406 2N bottom coverstitch	8gg / 3.2mm	10	folder 1T-5/16" finish binding	Fly	T18 Txt Poly	Side A	T18 Txt Poly	Side B	
Seam panel with tape.	607 4N flatseam-no topcover	16gg / 6.4mm	10	1/4" trimoff	Таре	T18 Txt Poly	Side A	T18 Txt Poly	Side B	
Bind legs with elastic/rubber.	406 2N bottom coverstitch	8gg / 3.2mm	12	folder 1T-9/16" finish binding	Leg	T24 Txt Poly	Side A	T18 Txt Poly	Side B	
Attach exposed elastic to waist.	407 3N bottom coverstitch	16gg / 6.4mm	12	5/16" overlap; 1/4" trimoff	Waist	T24 Txt Poly	Side A	T18 Txt Poly	Side B	
Flatseam crotch.	607 4N flatseam	16gg / 6.4mm	14	1/4" overlap; 1/4" trimoff	Body	T18 Txt Poly	Side A	T18 Txt Poly	Side B	
Set garment label (heat transfer) centered over band seam.	N/A	N/A	N/A	N/A		N/A		N/A		
APPROVED ALTERNATES:										
Alternate seaming to be used only where 607 flatseam is not available due to capacity (Requires prior approval).										
Attach pieces.	504 3 thread overedge	8gg / 3.2mm	12	3/8"; 1/4" trimoff		T18 Txt Poly	Side B	T18 Txt Poly	Side B	
Topcover seams.	605 3N topcover	16gg / 6.4mm	12	no trimoff		T18 Txt Poly	Side A	T18 Txt Poly	Side B	





# Documents


# 002 : Measurements - T0409A PMEAS




Piece	Pcs Per	]							=
Name:	Gmt:		Name	XS	S	M	L	XL	2X
T0409AFT	2		A	3"16	3"20	3"24	4"	4" 8	4"12
			В	10"10	10"26	11"26	12"22	13"14	14" 3
			С	3"16	3"20	3"24	4"	4" 8	4"12
			D	5" 9	5"13	6" 1	6" 1	6" 1	6" 5
			E	3"18	3"27	4" 2	4"27	5"18	6" 2
			F	1"23	1"27	1"31	2" 3	2" 3	2" 3
T0409ABK	( 1		G	7" 1	7"17	8"17	9"13	10" 5	10"25
			н	6"31	7"29	8"23	9"23	10"21	11" 5
			1	3"19	3"27	4"11	4"19	4"23	4"27
			J	7" 2	8"	9" 2	10" 8	11"15	12" 6
			К	1" 9	1"10	1"13	1"18	1"22	1"24

 $Note: All\ measurements\ are\ displayed\ in\ 32nds.\ Please\ refer\ to\ FlexPLM\ User\ Training\ Manual-PRODUCT\ SPECIFICATIONS\ for\ conversion\ chart.$ 

004 : Marker Layout - T0409A-60 FT,BK-70.5




004 : Marker Layout - T0409A-60 FT,BK-70.5




006 : Marker Layout - T0409A-60 FT,BK-35


## T0409A5XS




## T0409A5S




#### T0409A5M



## T0409A5L



## T0409A5XL




001 : Front/Back Image - Boys Ctn Knit Rib ExpWB




005 : Marker Layout - T0409A-60 FT,BK-31

T0409A4XS T0409A4S T0409A4M

005 : Marker Layout - T0409A-60 FT,BK-31




004 : Marker Layout - T0409A-60 FT,BK-70.5



001 : Front/Back Image - Boys Ctn Knit Rib ExpWB




003 : Front/Back Image - Flow in Elastic GP10188 Exposed Elastic Brief




# 003 : Marker Layout - T0409A-60 FT,BK-36.5


## T0409A1XS




## T0409A1S




#### T0409A1M



#### T0409A1L




## T0409A1XL




# 003 : Marker Layout - T0409A-60 FT,BK-36.5


## T0409A1XS




## T0409A1S




#### T0409A1M




#### T0409A1L



## T0409A1XL




005 : Marker Layout - T0409A-60 FT,BK-31




006 : Marker Layout - T0409A-60 FT,BK-35


## T0409A5XS




## T0409A5S




#### T0409A5M



## T0409A5L



## T0409A5XL



003 : Front/Back Image - Flow in Elastic GP10188 Exposed Elastic Brief



# 001 : Front/Back Image - Boys Ctn Knit Rib ExpWB




# 001 : Front/Back Image - Boys Ctn Knit Rib ExpWB




005 : Marker Layout - T0409A-60 FT,BK-31

T0409A4XS T0409A4S T0409A4M

003 : Front/Back Image - Flow in Elastic GP10188 Exposed Elastic Brief




# 002 : Measurements - T0409A PMEAS



Piece	Pcs Per							=:
Name:	Gmt:	Name	XS	S	M	L	XL	2X
T0409AFT	2	A	3"16	3"20	3"24	4"	4" 8	4"12
		В	10"10	10"26	11"26	12"22	13"14	14" 3
		С	3"16	3"20	3"24	4"	4" 8	4"12
		D	5" 9	5"13	6" 1	6" 1	6" 1	6" 5
		E	3"18	3"27	4" 2	4"27	5"18	6" 2
		F	1"23	1"27	1"31	2" 3	2" 3	2" 3
T0409ABK	( 1	G	7" 1	7"17	8"17	9"13	10" 5	10"25
		н	6"31	7"29	8"23	9"23	10"21	11" 5
		ı	3"19	3"27	4"11	4"19	4"23	4"27
		J	7" 2	8"	9" 2	10" 8	11"15	12" 6
		к	1" 9	1"10	1"13	1"18	1"22	1"24

Note: All measurements are displayed in 32nds. Please refer to FlexPLM User Training Manual-PRODUCT SPECIFICATIONS for conversion chart.


004 : Marker Layout - T0409A-60 FT,BK-70.5



#### 007: Pattern Information - T0409A

CAD Storage:

Variant Screenshot: UW-Youth



Trim- Straight Cut - Fly and Panel Tubing

Pattern Allowances:

Fly Length -1/8 Fly Position -1/4

Crotch Width -3/8 Trim- Bias Cut - Leg Binding

Leg Opening 98%


003 : Front/Back Image - Flow in Elastic GP10188 Exposed Elastic Brief




## 005 : Placement Details - LP016: Fitted UW Inside Waist (no CB seam)

LP006: Inside Waist (no CB seam)
Placement Finished Garment: Centered on Back; 1/2" Down From Stitch/Seam

Placements are to the center/highest point of the design







## 005 : Placement Details - LP016: Fitted UW Inside Waist (no CB seam)

LP006: Inside Waist (no CB seam)
Placement Finished Garment: Centered on Back; 1/2" Down From Stitch/Seam

Placements are to the center/highest point of the design






#### 007: Pattern Information - T0409A

CAD Storage:

Variant Screenshot: UW-Youth



Trim- Straight Cut - Fly and Panel Tubing

Pattern Allowances:

Fly Length -1/8 Fly Position -1/4

Crotch Width -3/8 Trim- Bias Cut - Leg Binding

Leg Opening 98%